



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

END CAP MOLDING NOTCH



#1 – Position face panel. Slide end cap down to rest on top edge of base molding.



#2 – Use straight edge to mark notch line down across base molding.



#3 – Scribe notch line with utility knife to score notch line.



#4 – Use sharp chisel with wide blade to carefully notch base molding (or Dremel).



#5 – Completely chisel out base molding notch.



#6 – Slide new end cap down into place.