



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

BAY WINDOW TOP RAIL WEDGE

REFER TO BAY WINDOW CORNER MEASURING INSTRUCTIONS PAGE



#1 – The measuring and layout for a bay window or non 90-degree corner is referenced on the *Bay Window Corner Measuring Instructions* and *Bay Window Installation* pages. Once the panels have been slipped into place, the final stage is to install the top rail wedge pieces.



#2 – This photo shows the two adjoining panels in place with left and right open end caps. You are now ready to install the top rail wedge piece that will cover this opening.



#3 – The top rail wedge piece is custom-made as per the customer-provided template described in the *Bay Window Measuring Instructions* page. The wedge piece will be secured with two dabs of adhesive caulk. This will allow for easy removal in the event that access is needed to the heating element fins.



#4 – This picture shows the finished bay window with multiple top rail wedge pieces.