



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com Web
Site: www.radiantwraps.com

PANEL NOTCH FOR EXTERIOR PLUMBING RUN



#1 – When a plumbing run extends out beyond the depth profile of a Radiant Wraps panel, the panel can be notched.



#2 – Position and mark the panel to layout the notch. Use a saber or band saw with a steel cutting blade to cut the notch. Use a file or grinding wheel to smooth the edges.



#3 – Paint the exposed steel on the notch with a Rustoleum-type product and slip the panel on over the exposed pipe.



#4 – Radiant Wraps recommends painting the copper tubing a dark color to minimize its appearance.