



134 Sand Park Road  
Cedar Grove, NJ 07009  
Phone: 973 857-6480 Fax: 973 857-4943  
E-Mail: Sales@radiantwraps.com  
Web Site: www.radiantwraps.com

## **INSTALLING FLASHING, WIRE SUPPORTS & MOUNTING BRACKETS** FOR INSTALLATIONS WHERE THE BACK PANEL IS MISSING OR HAS BEEN REMOVED



**#1** – The original baseboard enclosures have been removed (see *Removing Back Panel* page for detail).



**#2** – A 6-inch high coil of tin roof flashing should be rolled out and cut to cover the wall area. Paint the silver flashing with a flat black paint (Rustoleum).



**#3** – The painted tin flashing is slipped down along the wall to the floor and secured with staples, tacks, or roofing nails.



**#4** – A hook & eye screw, & wire support should be installed at 6" off the floor every 3 to 4 feet. (See *Hook & Eye Support* for detail).



**#5** – The mounting brackets are installed (see *Mounting Bracket Installation* page for more detail).



**#6** – The panels are then slipped into place so that the back flange slides down into the mounting bracket channel.