



134 Sand Park Road  
Cedar Grove, NJ 07009  
Phone: 973 857-6480 Fax: 973 857-4943  
E-Mail: Sales@radiantwraps.com  
Web Site: www.radiantwraps.com

## **SNIP & BEND HEIGHT ADJUSTMENT**



**#1** – Use metal snips and slice top rail from front to back. Be careful of sharp edges.



**#2** – Slice top rail into 10" to 12" sections.



**#3** – Using a heavy set of pliers, bend down each 10" to 12" section.



**#4** – Bend down entire top rail across the length of the back panel.



**#5** – Slide shims behind back panel and make final bend down to desired height.



**#6** – Slide new panel down into place.