



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

EXTENDED DEPTH CLEARANCE/SPACER BOARD INSTALLATION

WHEN THE DEPTH CLEARANCE REQUIRED FOR THE HEATING ELEMENT IS MORE THAN 3 5/16"



#1 – Remove existing back panel of enclosure to prepare for spacer board and flashing installation.



#2 – Create a template to mark where the top rail of the new Radiant Wraps panel will sit against wall (height is determined by the size option selected).



#3 – Install tin flashing and spacer board to the wall.



#4 – Paint or finish off the spacer board in the desired color.



#5 – Install mounting brackets to spacer board at the appropriate height off the floor.



#6 – Install new Radiant Wraps panels onto mounting brackets.